

Janome Quilting Feet & Applications

| | |
|------------------------|--|
| | AcuFeed Quilting |
| Foot Type | AcuFeed Dual Feed Foot - AD |
| Ideal Stitch | Straight Stitch + Straight Stitch Needle Plate |
| Setting Up Machine | <ul style="list-style-type: none"> • Attach the desired dual feed foot to the respective dual feed holder and attach to the machine. • Press the dual feed key and select the desired pattern. • Place the fabric under the foot and lower the needle at the point where you wish to start. Start sewing at medium speed. |
| Additional Information | <ul style="list-style-type: none"> • The dual feed device is extremely effective when sewing hard to feed materials such as PVC coated fabric or leather. It also eliminates layer slippage. • When seaming plaid fabrics, match the plaids of the upper and lower layers and pin them together. Remove the pins as you sew. |
| Optional Accessories | <ul style="list-style-type: none"> • Dual feed quilt piecing foot OD (twin): For 1/4" seam piecing with dual feed P/N: 202 125 004 • AcuFeed open toe foot UD (twin): For open toe better view sewing with dual feed P/N: 202 149 004 • AcuFeed ditch quilting foot SD (twin): For ditch quilting with dual feed P/N: 202 103 006 • AcuFeed straight stitch foot STD (twin): For accurate straight stitching with dual feed P/N: 202 102 005 |
| | Narrow AcuFeed Quilting |
| Foot Type | AcuFeed Single Dual Feed Foot - VD + ED |
| Ideal Stitch | Straight Stitch + Straight Stitch Needle Plate |
| Setting Up | <ul style="list-style-type: none"> • Attach the desired dual feed foot to the respective dual feed holder and attach to the machine. • Press the dual feed key and select the desired pattern. • Place the fabric under the foot and lower the needle at the point where you wish to start. Start sewing at medium speed. |
| Additional Information | <ul style="list-style-type: none"> • Ideal for narrow projects! Sometimes, the standard AcuFeed Flex™ twin system is just a little too bulky for very fine work. With the Single holder, you can enjoy all the benefits of AcuFeed Flex™ when you are creating more delicate projects. |
| Optional Accessories | <ul style="list-style-type: none"> • Dual feed foot VD (single): For sewing narrow areas with dual feed. P/N: 859 835 101 • Dual feed zipper foot ED (single): For zipper application with dual feed P/N: 859 838 001 |
| | Precise Narrow AcuFeed Quilting |
| Foot Type | AcuFeed Flex Profession Grade Foot – HP2 |
| Ideal Stitch | Straight Stitch + HP Needle plate |
| Setting Up | <ul style="list-style-type: none"> • Attach the HP Needle plate to the machine. • Select the Straight Stitch – the machine will only show stitches that allow left needle position. |
| Additional Information | <ul style="list-style-type: none"> • This foot provides superior visibility and is great for curves and precise topstitching. Holds fabrics firmly in sync with the feed dogs to achieve professional results. • Included part with the CM7P • Can be purchased for the MC15000QM, MC9450P, MC6700P |
| Optional Accessory | <ul style="list-style-type: none"> • For models compatible with Professional Grade Needle Plate P/N: 202415004 |
| | Rulerwork |
| Foot Type | Ruler work foot - QR |
| Ideal Stitch | Sewing Applications – Ruler work + Straight Stitch Needle Plate |
| Setting Up | <ul style="list-style-type: none"> • Attach the ruler work foot (QR) • Place the fabric under the ruler foot. • Adjust the presser foot height to suit the quilt thickness. • For ordinary and bulky quilts, select 2.5 for the foot height. • For flatter quilts, select 1.5 for the foot height. • You can fine adjust the presser foot height by pressing the “+” or “-” key. • Place the quilting template on the edge of the ruler work foot. • Sew while guiding the fabric and ruler together along the edge of the ruler foot. |
| Additional Information | <ul style="list-style-type: none"> • Guide the foot along the quilting template (optional) to create straight, curved or repetitious patterns depending on the shape of the ruler. |

- A ruler (quilting template) for ruler work sewing is required.
- Use the ruler (quilting template) for high shank or Longarm quilting machines (4.5 mm - 6.35 mm thickness).

| | |
|------------------------|---|
| | Clasp Quilting |
| Foot Type | Satin Stitch Foot - F |
| Ideal Stitch | Single motif stitches – Sewing Applications |
| Setting Up | Attach the 'F' foot to the machine Position the quilt under the foot in the required place and sew the single motif stitch. Once complete move quilt over and repeat as required. |
| Additional Information | You can close quilt layers and batting using the clasp stitch. The machine sews one unit of the pattern and automatically stops with the needle in up position when completed. |
| | Free Motion Quilting |
| Foot Type | Darning Foot – PD-H |
| Ideal Stitch | Straight Stitch with feed dogs lowered |
| Setting Up | <ul style="list-style-type: none"> • For ordinary and bulky quilts, attach the darning foot to the machine. • This foot bounces as you sew and relies on the needle bar going up and down to regulate the spring to bounce. |
| Additional Information | <ul style="list-style-type: none"> • Sew at medium speed while guiding the fabric with your hands. • Move the quilt 3 mm or less per stitch. |
| Optional Accessories | 9mm Hi/Shank – SKU: 859 839 002 9mm Hi/Shank Open Toe – SKU: 202 314 002 7mm Hi/Shank – SKU: 200 325 000 7mm Lo/Shank – SKU: 200 349 000 |
| | Free Motion Quilting |
| Foot Type | Closed Toe -QC, Open Toe -QO |
| Ideal Stitch | Straight Stitch – Sewing Applications menu only + Straight Stitch Needle Plate |
| Setting Up | <ul style="list-style-type: none"> • Select the straight stitch from the sewing applications menu • Attach the foot to the standard machines shank. This style of foot attached at the back and the front so that there is no movement in the foot while stitching. |
| Additional Information | Foot Height for Free Motion Quilting <ul style="list-style-type: none"> • When “Straight stitch 2” or “Zigzag stitch 2” is selected, the height of down position of the free motion quilting feet (QC, QO, QV) is optimized automatically. • However, you can fine tune the foot height according to the quilt thickness. Place the fabric under the foot and lower the foot. • Press the foot height key and the adjusting window opens. Adjust the foot height by pressing the “+” key or “-” key and press the OK key to register the setting. • Reduce the height if the fabrics bounce when sewing. • Increase the height if the foot gets trapped in the fabrics when sewing. |
| | Variable Zigzag |
| Foot Type | QZ or PD-H + Knee Lifter |
| Ideal Stitch | Sewing Applications – Quilting – Variable Zig Zag |
| Setting Up | <ul style="list-style-type: none"> • This unique feature allows you to control zigzag width with the knee lifter. • Select ‘M’ or ‘L’, using the darning foot PD-H for sewing quilt layers. The feed dog drops automatically. Guide the fabric with your hands while sewing. • Select ‘M’ or ‘L’, using the clear view free quilt foot QV or variable zigzag foot QZ • for sewing flat and firm fabrics. The feed dog drops automatically. Guide the fabric with your hands while sewing. • Sew at slow to medium speed while guiding the fabric with your hands and controlling the stitch width with your knee. |
| Additional Information | <ul style="list-style-type: none"> • When the machine stops, you can raise and lower the presser foot with the knee lifter. Maximum zigzag width adjustment <ul style="list-style-type: none"> • The maximum zigzag width can be limited to suit your sewing needs. • Press the “+” or “-” key beside the maximum zigzag width setting q to limit the maximum zigzag width to your preference. |
| | Free Motion Quilting |
| Foot Type | Convertible Free Motion Foot Set + QB-S |

| | |
|-----------------------------------|---|
| Ideal Stitch | Straight Stitch with feed dogs lowered |
| Setting Up | <ul style="list-style-type: none"> This set includes three feet that can be used with a variety of fabrics for free motion quilting projects. Attach the foot for the quilting you require onto the bottom of the holder. Attach the holder to the machine. Adjust the height of the foot – Lower the presser bar and adjust the screw so that the bottom of the foot barely touches the top of the quilt layers. |
| Additional Information | <ul style="list-style-type: none"> Closed-Toe Foot – Convenient for lace and other fabrics that catch on an open toe, this general use foot is also good for holding the fabric in front of the needle. Open-Toe Foot - Also for general use, but with greater visibility around the needle to assist formation of a precise design. Clear View Foot - The clear view foot moves smoothly over uneven layers such as fabric with cording or ribbon, and can also be used with zigzag stitches. |
| Optional Accessories | 9mm Hi/Shank (Excludes Pivot Models) – SKU: 202146001 7mm Hi/Shank – SKU: 202001003 7mm Lo/Shank – SKU: 202002004 |
| Sculpture Stitching - AD | |
| Foot Type | AcuFeed Quilting Feet AD + VD |
| Ideal Stitch | Sewing Applications – Sculpture Stitch |
| Setting Up | <ul style="list-style-type: none"> Attach the preferred foot for the application to the machine. Select the required stitch and sew. |
| Additional Information | <ul style="list-style-type: none"> These stitches are used to accentuate design outlines and to create a mock hand-quilt. The stitches can also be used as a faux sashiko stitch |
| Hand Look Quilting | |
| Foot Type | Satin Stitch - F |
| Ideal Stitch | Sewing Applications – Hand Look |
| Setting Up | <ul style="list-style-type: none"> Use a transparent nylon thread for the needle and ordinary sewing thread for the bobbin. The bobbin thread is pulled up on the right side of the fabric and the stitches will look as if sewn by hand. |
| Additional Information | <ul style="list-style-type: none"> The tension for this stitch is pre-set to a higher tension when this application is selected and can be adjusted if necessary Recommended to use a monofilament or light weight 60-100wt thread |
| Convertible Even Feed Foot | |
| Foot Type | Convertible Even Feed Foot with guides and open toe attachment |
| Ideal Stitch | Straight Stitch |
| Setting Up | <ul style="list-style-type: none"> Attach foot to the machine with the lever over the needle clamp. Attach the preferred sole and guides to the foot Sew at a medium speed so the foot can help to prevent fabrics from slipping or puckering |
| Additional Information | Using the Quilting Guide Bar <ul style="list-style-type: none"> The quilting guide bar is helpful when sewing parallel, evenly spaced rows of stitches. Insert the quilting guide bar into the hole in the back of the foot holder. Slide the quilting guide bar and set it to the desired spacing. Sew rows of stitches while tracing the previous row of stitches with the quilting guide bar. |
| Optional Accessories | 9mm Hi/Shank – SKU: 202 133 005 7mm Hi/Shank – SKU: 214 516 003 7mm Lo/Shank – SKU: 214 517 004 |
| Decorative Stitch Quilting | |
| Foot Type | AcuFeed Dual Feed – AD with Manual function activated on CM7P |
| Ideal Stitch | Decorative forward moving stitches |
| Setting Up | <ul style="list-style-type: none"> Select the Function Menu key Turn on the Manual AcuFeed Setting Return the decorative stitching tab and select the stitches to sew onto the quilt Position the Quilt and sew at medium speed. |
| Additional Information | <ul style="list-style-type: none"> You can decorate the seam on the quilt or patchwork fabric with the decorative quilt stitches. |